

CARING FOR OUTDOOR FURNITURE

Outdoor furniture is designed to withstand the elements, but regular maintenance is essential to keep it looking its best and prolong its lifespan. Proper cleaning, protective treatments, and thoughtful storage can help prevent damage from weather, UV exposure, and general wear.

REGULAR CLEANING

Frequency :

Clean your outdoor furniture regularly, especially after heavy use or prolonged exposure to the elements.

Method :

- Use a soft brush to remove loose dirt and debris.
- Mix mild dish soap with water and wipe down surfaces using a soft cloth or sponge
- For stubborn stains, gently scrub with a soft-bristle brush.
- Rinse thoroughly with clean water and allow to dry completely before use.

Avoid :

Harsh chemicals, abrasive cleaners, and high-pressure washers, as they can cause damage to finishes and materials.

ADDITIONAL PROTECTION

Covers :

We highly recommend using covers when furniture is not in use to protect against UV exposure, rain, and debris, helping to maintain its quality for years to come.

Storage :

- Remove cushions and store them indoors when not in use to prevent mold and fading.
- Ensure all furniture is clean and completely dry before covering or storing to prevent mildew and rust.